FAIRFAX COUNTY HEALTH DEPARTMENT ENVIRONMENTAL HEALTH DIVISION AIR MONITORING AND TRENDS ANALYSIS 10777 MAIN STREET, SUITE 115 FAIRFAX VIRGINIA 22030

DIRECTIVE 2 MONITORING AND REPORTING REQUIREMENTS FOR ACTINOLITE/TREMOLITE SOIL SOURCES

I. Monitoring Requirements

- A. The monitoring and sample analysis will be conducted by competent personnel and closely supervised by an experienced individual certified with NIOSH 582 course training or equivalent.
- B. Air monitoring samples will be collected.
 - 1. They may be perimeter and/or area monitoring samples.
 - 2. They are to be representative samples of the emissions downwind of the work activities.
 - 3. They may be obtained at any on-site, downwind location, up to and including the point demarcating public areas.
 - 4. They will be analyzed by the NIOSH 7400 method. Confirmatory transmission electron microscopy (TEM) may be used as an option.
 - 5. Overloaded air monitoring sample filters that can not be analyzed by the NIOSH 7400 method will be archived. A qualitative report as to the presence or absence of fibers along with a reason for the inability to analyze the filters will be included in the Project Report. **NOTE:** Overloaded samples will be considered an indication of excessive fugitive dust resulting from inadequate dust control.
- C. Project Reports of the perimeter, area, and personal monitoring results will be submitted to this office.
 - 1. Reports will be submitted in a timely fashion.
 - 2. Reports concerning violations to Directive 1 will be submitted immediately upon discovery.

II. Project Report Requirements.

- A. A written description of the work activities.
 - 1. Methods used to investigate for the presence and forms of actinolite/tremolite minerals at the site.
 - 2. Work activities with the potential to generate fugitive dust emissions.
 - 3. Evaluation of the site to identify potential problem areas including such features as areas of high emission potential, areas likely to produce maximum off site impacts, etc.
 - 4. Daily weather and soil conditions at the construction project, to include but not limited to wind direction, wind speed, precipitation, and approximate soil moisture.

B. Diagram of the Construction Project.

- 1. The diagram is at least an 8 by 11 inch copy of the project site drawings.
- 2. Label diagram to include perimeters.
- 3. Identify the work activities.
- 4. Label the air monitors.
- 5. Indicate wind direction during air monitoring.

C. Air Monitoring Results.

- 1. Sample date.
- 2. Monitor location.
- 3. Date of last calibrations for samplers.
- 4. Interpretations of data and exposure potential.
- 5. Explanation of voided samples to include the possible cause, and a qualitative report as to the presence or absence of fibers (Non-NIOSH 7400 methods allowed).
- 6. Sample results:
 - a. Asbestos concentration in fibers per cubic centimeter of air, reported to two decimal places.
 - b. Duration of sample in minutes.
 - c. Rate of sample flow in liters/minute.

D. Violations to DIRECTIVE 1 detected by air monitoring.

- 1. Suspected cause for each violation.
- 2. Best estimate of duration and magnitude of fiber release, areas exposed, and supporting rationale.
- 3. Actions taken to prevent similar violations in the future.

III. The 24-hour average standard is calculated by:

$$(W X S) + (2 X MDC) + \{[24 Hrs. - (W + 2 Hrs.)] X 0.005 F/CC\}$$

24 Hrs.

Where:

W = Work Day in Hours.

S = Sample results in Fibers per Cubic Centimeter.

MDC = Mean Decay Period Concentration (Concentration decays to background levels during the two hours following the end of the workday).

$$= \underbrace{Start\ Concentration + End\ Concentration}_{2} = \underbrace{S + 0.005}_{2}$$

(NOTE: Since 2 X MDC = 2 X
$$(S + 0.005)$$
 = S + 0.005 \approx S

S may be substituted for 2 X MDC as a simplification.)

0.005 F/CC is the approximate background concentration.